

STICKER PLACEMENT GUIDE



Included in this package are three stickers:

1. Your surcharge sticker
2. A sticker with contact and service information
3. Your ATM Network Service sticker, which displays all of the card types accepted on your ATM.

Here's where the stickers should go:



To report suspicious activity or operational problems with this ATM, please contact:
ATM Help Desk 1-888-486-4949.
PLUS transactions are sponsored by Citizens Bank.
For sales, service or questions regarding ATMs, please call
ATM Network, Inc
1-800-929-0228